
Instruction For Use / Käyttöohjeet

1. Set all dials to 0 (zero) to open the lock, by aligning numbers with the indication line on the face of lock. (diagram 1)
2. Turn the shackle 180° clockwise so that the notch of the shackle is aligned with the opening on the body. Press down the shackle (diagram 2).
3. Turn the shackle 90 ° or more counter-clockwise and turn dials to set your personal combination (diagram 3).
4. Turn the shackle clockwise so that it's 180° from the locking position. Pull up the shackle and your lock is now ready to use.



1. Aukaise lukko asettamalla kaikki luvut nolliksi merkkiviivan kohdalle ja vetämällä sitten sanka ylös (kuva 1).
2. Käännä sankaa myötäpäivään 180° (kuva 2).
3. Paina sanka alas ja käännä sitä takaisin vastapäivään 90°. Nyt voit asettaa oman numerokoodin merkkiviivan kohdalle (kuva 3).
4. Käännä taas sankaa myötäpäivään samaan asentoon kuin se oli kohdassa 2 (180° alkuperäisestä asennosta) ja vedä sanka ylös. Nyt lukko toimii asettamallasi numerokoodilla.

pisla